

SAJ



GUANGZHOU SANJING ELECTRIC CO.,LTD




Tel: (86)20 66608588 Fax: (86)20 66608589 Web: www.saj-electric.com

Add: SAJ Innovation Park, No.9, Lizhishan Road, Science City, Guangzhou High-tech Zone, Guangdong, P.R.China

V0.0

SAJ



H2 Series

HYBRID SOLAR INVERTER

USER MANUAL

H2-(10K-30K)-(T2, T3)-AU

Preface

Thank you for choosing SAJ products. We are pleased to provide you first-class products and exceptional service.

This manual provides information about installation, operation, maintenance, troubleshooting and safety. Please follow the instructions of this manual so that we can ensure delivery of our professional guidance and whole-hearted service.

Customer-orientation is our forever commitment. We hope this document proves to be of great assistance in your journey for a cleaner and greener world.

We make constant improvements on the products and their documentation. This manual is subject to change without notice; these changes will be incorporated in new editions of the publication. To access the latest documentation, visit the SAJ website at <https://www.saj-electric.com/>.

Guangzhou Sanjing Electric Co., Ltd.



TABLE OF CONTENTS

1. SAFETY PRECAUTIONS.....	1	4.4.2. Installing an RCD (optional).....	26
1.1. Application Scope.....	2	4.4.3. Connecting the Grid and Backup Loads.....	26
1.2. Safety.....	2	4.5. Assembling the Communication Connection.....	28
1.2.1. Safety Levels.....	2	4.6. Connecting the BMS.....	30
1.2.2. Symbol Explanation.....	3	4.7. Assembling the PV-side Electrical Connection.....	32
1.2.3. Safety Instructions.....	4	4.8. Installing the Communication Module.....	35
1.3. Safe Handling.....	5	4.9. Earth Fault Alarm.....	35
2. Product Overview.....	7	4.10. System connection.....	36
2.1. General Introduction.....	8	4.11. System Application Diagram.....	37
2.2. Unpacking.....	9	4.12. AFCI.....	37
2.3. Dimension.....	10	5. Startup and Shutdown.....	39
2.4. Datasheet.....	11	5.1. Starting the Inverter.....	40
3. Installation Instructions.....	17	5.1.1. Introduction to the LED Indicators.....	40
3.1. Determining the Installation Position.....	18	5.2. Shutting Down the Inverter.....	42
3.1.1. Installation Environment Requirements.....	18	6. Commissioning.....	43
3.1.2. Installation Location Requirements.....	18	6.1. Installing the App.....	44
3.2. Mounting Procedure.....	20	6.2. Logging In to the App and Performing the Initialization Settings.....	44
3.2.1. Installation Tools.....	20	6.3. Setting the Protection Parameters.....	47
3.2.2. Mounting Procedures.....	21	6.4. Reviewing the Inverter Settings.....	48
4. Electrical Connection.....	23	6.5. Configuring the Remote Monitoring.....	48
4.1. Safety Instructions.....	24	6.6. Selecting the Working Mode.....	49
4.2. Port.....	24	6.7. Configuring the Export Limit.....	50
4.3. Grounding.....	25	6.8. Configuring the Reactive Power Control.....	50
4.4. Assembling the AC-side Electrical Connection.....	26	7. Troubleshooting.....	55
4.4.1 Installing a Circuit Breaker.....	26	8. Appendix.....	59
		8.1. Recycling and Disposal.....	60
		8.2. Transportation.....	60
		8.3. Warranty.....	60
		8.4. Contacting Support.....	60
		8.5. Trademark.....	60

1.

SAFETY PRECAUTIONS



1.1. Application Scope

This user manual describes instructions and detailed procedures for installing, operating, maintaining, and troubleshooting of the following SAJ hybrid solar inverters:

H2-10K-T3-AU	H2-12K-T3-AU	H2-15K-T2-AU	H2-15K-T3-AU
H2-20K-T2-AU	H2-20K-T3-AU	H2-25K-T3-AU	H2-30K-T3-AU

Please read the user manual carefully before any installation, operation and maintenance and follow the instruction during installation and operation. Please keep this manual all time available in case of emergency.


Only qualified electricians who have read and fully understood all safety regulations contained in this manual can install, maintain, and repair the inverter. Operators must be aware that it is a high-voltage device.


1.2. Safety


CAUTION:


ONLY qualified and trained electricians who have read and fully understood all safety regulations contained in this manual can install, maintain, and repair the equipment.

1.2.1. Safety Levels











 DANGER
Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



 WARNING
Indicates a hazardous situation which, if not avoided, can result in death or serious injury or moderate injury.

 CAUTION
Indicates a hazardous condition which, if not avoided, can result in minor or moderate injury.

 NOTICE
Indicates a situation that can result in potential damage, if not avoided.


1.2.2. Symbol Explanation


Symbol	Description
	Danger: Electrical shock hazard This device is directly connected to public grid, thus all work to the battery shall only be carried out by qualified personnel.
	WARNING: No open flames Do not place or install near flammable or explosive materials.
	Danger: Hot surface The components inside the battery will release a lot of heat during operation. Do not touch metal plate housing during operating.
	Attention: Install the product out of reach of children.
	Attention: Check the user manual before service. If an error has occurred, refer to the troubleshooting chapter to remedy the error.
	Attention: This device shall NOT be disposed of in residential waste.
	Attention: This battery module shall NOT be disposed of in residential waste.
	CAUTION: Risk of electric shock from energy stored in capacitor. Do not remove cover until 5 minutes after disconnecting all sources of supply
	CE Mark Equipment with the CE mark fulfills the requirements of the Low Voltage Directive and Electro Magnetic Compatibility.
	RoHS compliant mark Equipment with the RoHS mark does not exceed the allowable amounts of the restricted substances defined in Restriction of Hazardous Substances in Electrical and Electronic Equipment.


	RCM compliant mark Equipment with the RCM mark is in compliance with AS/NZS 4417.1 & 2 and the EESS.
	Recyclable

1.2.3. Safety Instructions

For safety, be sure to read all the safety instructions carefully prior to any works, and please observe the appropriate rules and regulations of the country or region where you.

 DANGER
<ul style="list-style-type: none"> • There is possibility of dying due to electrical shock and high voltage. • Do not touch the surface of the equipment while the housing is wet, otherwise, it might cause electrical shock. • Do not touch the operating component of the device; it might result in burning or death. • To prevent risk of electric shock during installation and maintenance, please make sure that all AC and DC terminals are plugged out. • Do not stay close to the equipment while there are severe weather conditions including storm, lightning, etc. • Before opening the housing, the SAJ inverter must be disconnected from the grid and PV generator; you must wait for at least five minutes to let the energy storage capacitors completely discharged after disconnecting from power source. • Please keep the power off prior to any operations.

 WARNING
<ul style="list-style-type: none"> • Only qualified personnel who has full knowledge of local safety regulations and local standards on battery can install, maintain, retrieve, and process this product. • SAJ electric shall not be liable for any loss or warranty claims arising from any unauthorized change of product which may cause fatal injury to the operator, third party or equipment performance. • For personal and property safety, do not short-circuit the positive (+) and negative (-) electrode terminals.


 CAUTION
<ul style="list-style-type: none"> • The inverter will become hot during operation. Please do not touch the heat sink or peripheral surface during or shortly after operation. • Risk of damage due to improper modifications.

! NOTICE

- Public utility only.
- The inverter is designed to feed AC power directly to the public utility power grid; do not connect AC output of the inverter to any private AC equipment.

1.3. Safe Handling

- Only qualified electricians who have read and fully understood all safety regulations in this manual can install, maintain, and repair the inverter.
- When the inverter is working, do not touch the internal components or cables to avoid electric shock.
- When the inverter is working, do not plug in or out the cables.
- Make sure that the AC input voltage and current are compatible with the rated voltage and current of the inverter; otherwise, components might be damaged, or the device cannot work properly.



2.


PRODUCT OVERVIEW




2.1. General Introduction

The H2 series inverter is a hybrid photovoltaic inverter which is applicable to both on-grid and off-grid solar systems. The energy generated by the photovoltaic (PV) system will be fed to loads first, the surplus energy will charge the battery for later use, and if there is still excess more energy, it will be exported to the grid.

The H2 inverter can significantly improve the self-consumption rate of solar energy and lower the dependency on grid.




2.2. Unpacking



The documents include the user manual, quick installation guide, warranty card and packaging list.

2.3. Dimension



2.4. Datasheet

H2-(10K-20K)-(T2, T3)-AU

Model	H2-10K-T3-AU	H2-12K-T3-AU	H2-15K-T2-AU	H2-15K-T3-AU	H2-20K-T2-AU
DC Input					
Max. PV Array Power [Wp]@STC	20000	24000	30000	30000	30000
Max. DC Voltage [V]	1000				
MPPT Voltage Range [V]	180 - 900				
Rated DC Voltage [V]	600				
Start Voltage [V]	180				
Over voltage Category (OVC)	II				
Max. DC Input Current [A]	40/40/40		40/40	40/40/40	40/40
Max. DC Short Circuit Current [A]	50/50/50		50/50	50/50/50	50/50
No. of MPPT	3		2	3	2
Number of String per MPP Tracker	2/2/2		2/2	2/2/2	2/2
Battery Port Connection					
Battery Type	LiFePO4				
Battery Voltage Range [V]	180 - 800				
Max. Charging/Discharging Current [A]	2*50				
AC Output [On-grid]					
Rated AC Power [W]	9999	12000	15000	15000	20000
Rated Apparent Power [VA]	9999	12000	15000	15000	20000
Max. Apparent Power [VA]	9999	13200	16500	16500	22000
Rated Output Current [A]@230Vac	14.5	17.4	21.8	21.8	29.0
Max. AC Output Current to Utility Grid [A]	14.5	19.2	24.0	24.0	31.9
Current Inrush [A]	120				
Max. AC fault Current [A]	64				
Max. AC over Current Protection [A]	95.5				
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485				
Rated Output Frequency/Range [Hz]	<ul style="list-style-type: none"> ● 50 Hz: 45 - 55 ● 60 Hz: 55 - 65 				
Power Factor [cos φ]	0.8 leading - 0.8 lagging				

Model	H2-10K-T3-AU	H2-12K-T3-AU	H2-15K-T2-AU	H2-15K-T3-AU	H2-20K-T2-AU
Total Harmonic Distortion [THDi]	<3%				
Over voltage Category (OVC)	III				
AC Input [On-grid]					
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485				
Rated Input Frequency [Hz]	50, 60				
Max. Input Current [A]@230Vac	28.3	28.3	28.3	28.3	37.7
AC Output [Back-up]					
Max. Output Power [VA]	10000	12000	15000	15000	20000
Max. Output Current [A]	14.5	17.4	21.8	21.8	29.0
Peak Output Apparent Power [VA]	15000, 3S	18000, 3S	22500, 3s	22500, 3s	30000, 3s
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485				
Rated Output Frequency/Range [Hz]	<ul style="list-style-type: none"> ● 50 Hz: 45 - 55 ● 60 Hz: 55 - 65 				
Output THDv (@ Linear Load)	<3%				
Efficiency					
Max. Efficiency	98.0%				
Euro Efficiency	97.6%				
Protection					
Battery Input Reverse Polarity Protection	Integrated				
Over Load Protection	Integrated				
AC Short Circuit Current Protection	Integrated				
DC Surge Protection	Type II				
AC Surge Protection	Type II				
Anti-islanding Protection	AFD				
AFCI Protection	Integrated				
Interface					
PV Connection	D4,MC4 (Optional)				
AC Connection	Terminal block				
Battery Connection	Quick connector				
Display	LED+App				
Communication	Wi-Fi/Ethernet/4G (Optional)				
General Parameters					
Topology	Non-isolated				
Operating Temperature Range	-40°C to +60°C (45°C and above with derating)				
Cooling Method	Intelligent fan cooling				
Ambient Humidity	0 - 100% Non-condensing				
Altitude	4000m (>3000m Power Derating)				


Model	H2-10K-T3-AU	H2-12K-T3-AU	H2-15K-T2-AU	H2-15K-T3-AU	H2-20K-T2-AU
Noise [dBA]	<50				
Ingress Protection	IP65				
Dimensions [H*W*D] [mm]	576*659*242				
Weight [kg]	50				
Warranty [Year]	Refer to the warranty policy				
Standard	EN 62109-1/2, EN 61000-6-2/4, EN 50438, EN 50549, C10/11, IEC 62116, IEC 61727, RD 1699, RD 413, UNE 206006, UNE 206007, NTS, CEI 0-16, CEI 0-021, AS 4777.2, NBR 16149, NBR 16150 VDE-AR-N 4105, VDE 0126-1-1				

H2-(20K-30K)-T3-AU

Model	H2-20K-T3-AU	H2-25K-T3-AU	H2-30K-T3-AU
DC Input			
Max. PV Array Power [Wp]@STC	40000	45000	45000
Max. DC Voltage [V]	1000		
MPPT Voltage Range [V]	180 - 900		
Rated DC Voltage [V]	600		
Start Voltage [V]	180		
Over voltage Category (OVC)	II		
Max. DC Input Current [A]	40/40/40		
Max. DC Short Circuit Current [A]	50/50/50		
No. of MPPT	3		
Number of String per MPP Tracker	2/2/2		
Battery Parameters			
Battery Type	LiFePO4		
Battery Voltage Range [V]	180 - 800		
Max. Charging/Discharging Current [A]	2*50		
AC Output [On-grid]			
Rated AC Power [W]	20000	25000	29999
Rated Apparent Power [VA]	20000	25000	29999
Max. Apparent Power [VA]	22000	27500	29999
Rated Output Current [A]@230Vac	29.0	36.3	43.4
Max. AC Output Current to Utility Grid [A]	31.9	39.9	43.4
Current Inrush [A]	120	180	

Model	H2-20K-T3-AU	H2-25K-T3-AU	H2-30K-T3-AU
Max. AC fault Current [A]	64	95	
Max. AC over Current Protection [A]	95.5		
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485		
Rated Output Frequency/Range [Hz]	<ul style="list-style-type: none"> ● 50 Hz: 45 - 55 ● 60 Hz: 55 - 65 		
Power Factor [cos φ]	0.8 leading - 0.8 lagging		
Total Harmonic Distortion [THDi]	<3%		
Over voltage Category (OVC)	III		
AC Input [On-grid]			
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485		
Rated Input Frequency [Hz]	50, 60		
Max. Input Current [A]@230Vac	37.7	47.2	56.5
AC Output [Back-up]			
Max. Output Power [VA]	20000	25000	30000
Max. Output Current [A]	29.0	36.3	43.5
Peak Output Apparent Power [VA]	30000, 3s	37500, 3s	45000, 3s
Rated AC Voltage/Range [V]	3+N+PE, 220/380, 230/400, 240/415; 180 - 280/312 - 485		
Rated Output Frequency/Range [Hz]	<ul style="list-style-type: none"> ● 50 Hz: 45 - 55 ● 60 Hz: 55 - 65 		
Output THDv (@ Linear Load)	<3%		
Efficiency			
Max. Efficiency	98.0%		
Euro Efficiency	97.6%		
Protection			
Battery Input Reverse Polarity Protection	Integrated		
Over Load Protection	Integrated		
AC Short Circuit Current Protection	Integrated		
DC Surge Protection	Type II		
AC Surge Protection	Type II		
Anti-islanding Protection	AFD		
AFCI Protection	Integrated		
Interface			
PV Connection	D4,MC4 (Optional)		
AC Connection	Terminal block		
Battery Connection	Quick connector		
Display	LED+App		
Communication	Wi-Fi/Ethernet/4G (Optional)		

Model	H2-20K-T3-AU	H2-25K-T3-AU	H2-30K-T3-AU
General Parameters			
Topology	Non-isolated		
Operating Temperature Range	-40°C to +60°C (45°C and above with derating)		
Cooling Method	Intelligent fan cooling		
Ambient Humidity	0 - 100% Non-condensing		
Altitude	4000m (>3000m Power Derating)		
Noise [dBA]	<50		
Ingress Protection	IP65		
Dimensions [H*W*D] [mm]	576*659*242		
Weight [kg]	50		
Warranty [Year]	Refer to the warranty policy		
Standard	EN 62109-1/2, EN 61000-6-2/4, EN 50438, EN 50549, C10/11, IEC 62116, IEC 61727, RD 1699, RD 413, UNE 206006, UNE 206007, NTS, CEI 0-16, CEI 0-021, AS 4777.2, NBR 16149, NBR 16150 VDE-AR-N 4105, VDE 0126-1-1		



3.

INSTALLATION INSTRUCTIONS



DANGER


- Dangerous to life due to potential fire or electricity shock.
- Do not install the inverter near any inflammable or explosive items.

NOTICE

- This equipment meets the pollution degree.
- Inappropriate or the harmonized installation environment may jeopardize the life span of the inverter.
- Installation directly exposed under intensive sunlight is not recommended.
- The installation site must be well ventilated.

3.1 Determining the Installation Position

3.1.1. Installation Environment Requirements




- Do not expose the device to direct solar irradiation as this could cause power derating due to overheating.
- The installation environment must be free of inflammable or explosive materials.
- The device must be installed in a place away from any heat source.
- Do not install the device at a place where the temperature changes extremely.
- Keep the device away from children.
- Do not install the device at daily working or living areas, including but not limited to the following areas: bedroom, lounge, living room, study, toilet, bathroom, theater, and attic.
- When installing the device at the garage, keep it away from the driveway.
- Keep the device from water sources such as taps, sewer pipes and sprinklers to prevent water seepage.
- The product is to be installed in a high traffic area where the fault is likely to be seen.

NOTE: When installing outdoors, the height of the device from the ground should be considered to prevent the device from soaking in water. The specific height is determined by the site environment.


3.1.2. Installation Location Requirements

- The device employs Intelligent fan cooling, and it can be installed indoor or outdoor.

- Install the device vertically. Do not install it forward-tilted, horizontally or upside down.



- Choose a solid and smooth wall to ensure that the inverter can be installed securely on the wall. Make sure that the wall can bear the weight of the inverter and accessories.
- Reserve enough clearance around the inverter to ensure a good air circulation at the installation area, especially when multiple inverters need to be installed in the same area.



3.2. Mounting Procedure

3.2.1. Installation Tools



Installation tools include but are not limited to the following recommended ones. Please use other auxiliary tools on site if necessary.



3.2.2. Mounting Procedures


1. Place the mounting bracket horizontally onto the wall by using a gradienter and mark the four holes on the wall.

Note: If required, reserve enough distance at the inverter bottom for installing the metal cable conduits.




2. Install the mounting bracket to the wall.

- ① Drill four holes in the mark positions on the wall.
- ② Use a rubber mallet to insert the plastic expansion bolts into the holes.
- ③ Align the holes in the mounting bracket to the drilled holes in the wall.
- ④ Install the screws.



3. Carefully mount the inverter into the mounting bracket. Tighten the screws to secure the inverter.



4.

ELECTRICAL
CONNECTION

4.1. Safety Instructions

Electrical connection must only be operated on by professional technicians. Please keep in mind that the inverter is a bi-power supply equipment. Before connection, necessary protective equipment must be employed by technicians including insulating gloves, insulating shoes and safety helmet.


 **DANGER**


- Dangerous to life due to potential fire or electricity shock.
- Do not install the inverter near any inflammable or explosive items.
- Dangerous to life due to potential fire or electricity shock.
- When it is powered on, the equipment should in conformity with national rules and regulations.
- The direct connection between the inverter and high voltage power systems must be operated by qualified technicians in accordance with local and national power grid standards and regulations.
- The PV arrays will produce lethal high voltage when exposed to sunlight.

 **NOTICE**


Any improper operation during cable connection can cause device damage or personal injury

4.2. Port



Callout	Name	Description
A	DC SWITCH	Direct current (DC) switch. You can turn it to OFF or ON position.
B	MPPT1	PV input
C	MPPT2	PV input
D	MPPT3	PV input
E	BAT1+, BAT1-	Battery input
F	BAT2+, BAT2-	Battery input
G		Grounding
H	4G/WIFI	4G, Wi-Fi, and Ethernet
I	LAN, CAN, PART1, PART2, EMS, RS485, METER, DRMs	Communication port
J	BACK-UP	For connecting to backup loads
K	GRID	For connecting to the grid

4.3. Grounding



4.4. Assembling the AC-side Electrical Connection

4.4.1. Installing a Circuit Breaker

For safety operation and regulation compliance, install air circuit breaker between the grid and the inverter.

Inverter type	Recommended breaker specification
H2-(10K-20K)-(T2, T3)-AU	50A
H2-(25K-30K)-T3-AU	63A
Note: Do not connect multiple inverters to one AC circuit breaker.	

By installing a circuit breaker, the inverter can be disconnected from the grid quickly and safely when the integrated leakage current detector of the inverter detects that the leakage current exceeds the limitation.

4.4.2. Installing an RCD (optional)

An external residential current device (RCD) is not required since the inverter is integrated with a residential current monitoring unit (RCMU). However, if the external RCD must be installed according to the local regulations, either type A or B RCD can be installed with the action current 300 mA.

4.4.3. Connecting the Grid and Backup Loads

Prerequisite

Select cables according to the below specification. You can amplify appropriate diameter selection of the alternating current (AC) cable for the long grid-connection distance.


Type	Cable cross-sectional area (mm ²)	
	Range	Recommend
H2-(10K-30K)-(T2, T3)-AU	10 - 16	16
Additional grounding cable cross-sectional area (mm ²): 8		

Procedure


1. Open the waterproof cover, loosen the nut from the cable gland on the waterproof cover, insert the AC cable through the AC waterproof hole.



2. Connect the cables to the conductors L1, L2, L3, N, and PE. Secure the waterproof cover to the inverter.



3. Tighten the nut back to the cable gland.




4.5. Assembling the Communication Connection



EMS/METER		RS485_PC1/RS485_PC2		DRM	
1	NC	1	NC	1	DRM1/5
2	NC	2	NC-	2	DRM2/6
3	NC	3	NC	3	DRM3/7
4	NC	4	NC	4	DRM4/8
5	NC	5	NC	5	RefGen
6	NC	6	NC	6	Com/DRM0
7	RS485-A	7	RS485-A	7	V+
8	RS485-B	8	RS485-B	8	V-

CAN1/CAN2		PART1/ PART2		LAN	
1	NC	1	CANH PAR	1	TX+
2	NC	2	CANL PAR	2	TX-
3	NC	3	NC	3	RX+
4	CANH	4	SYN-BUS+	4	NC
5	CANL	5	NC	5	NC
6	NC	6	HOST-BUS+	6	RX-
7	NC	7	NC	7	NC
8	NC	8	TRF-BUS+	8	NC

Thread the communication cable through the waterproof cable gland and connect to the corresponding port. Tighten screws to secure the waterproof cover to the inverter. (M4*10mm screw; 0.6-0.8 N·m)



4.6. Connecting the BMS

Prerequisite


- The battery management system (BMS) (including the battery control unit and battery packs) has been installed.
- The BMS is powered off.
- Prepare the cables according to the below specifications:

Cable Cross-sectional area (mm ²)	
Range	Recommended value
8 - 10	8


- The positive cable is connected to the positive port BAT+ of the battery control unit, and the negative cable is connected to the negative port BAT- of the battery control unit.

Procedure



1. Get the waterproof cover from the accessory bag and cut holes in the rubber plug. Insert the positive and negative cables through the hole.
2. On both cables, use a 3-mm wide-bladed screwdriver to strip the insulation layer around 8 to 10 mm length from one cable end.




3. Insert the cable ends to the corresponding sleeves. Use a crimping plier to assembly the cable ends.




4. Insert the assembled cable ends into the blue positive and negative battery connectors. Then, gently pull the cables backwards to ensure that they are firmly connected.



5. Tighten the nuts on the positive and negative cable connectors.



6. Connect the cables to the BAT+ and BAT- ports on the inverter.



-- End

4.7. Assembling the PV-side Electrical Connection

About this task

- The inverter cannot be used with functionally earthed PV arrays.
- A positive connector and a negative connector are provided in the accessory bag.




Prerequisite

- The PV array is properly insulated to ground before it is connected to the inverter.
- Select cables according to the below specification.


Conductor cross-sectional area of cables (mm ²)		Conductor material
Scope	Recommended value	Outdoor copper wire cable, complying with 1000 VDC
4.0 - 6.0	4.0	

- The positive cable is connected to the positive side of the solar panels, and the negative cable is connected to the negative side of the solar panels.
- The DC switch on the inverter is in OFF position. For further safety considerations, use a reliable tool (such as a lock with a key) to lock the switch, so that others cannot unlock it easily.




Procedure


1. Insert the positive and negative cables through the hole in the waterproof cover.
2. Use a 3-mm wide-bladed screwdriver to strip the insulation layer around 8 to 10 mm length from one end of each cable.





3. Insert the cables ends to the sleeves. Use a crimping plier to assembly the cable ends.
4. Insert the assembled cables ends into the positive and negative connectors. Gently pull the cables backwards to ensure firm connection.




5. Tighten the lock screws on the positive and negative cable connectors.



6. Connect the positive and negative cables connectors into the positive and negative PV ports on the inverter. After you hear a “click” sound, the cables are firmly connected.




7. Install the waterproof cover for PV and battery ports. Tighten the screws.



-- End

4.8. Installing the Communication Module



Plug in the communication module to 4G/WIFI port and secure the module by rotating the nut.

Either an eSolar 4G module, eSolar Wi-Fi module, or eSolar AIO3 module can be connected to the 4G/WIFI port. For operation details, refer to the documentation shipped in the module package or go to <https://www.saj-electric.com/> for downloads.

4.9. Earth Fault Alarm


This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring. If an earth fault alarm occurs, the ring light on the inverter LED panel will be lit up in red and an error code <31> can be viewed on the Elekeeper App.

NOTE: The inverter cannot be used with functionally earthed PV arrays.

4.10. System connection


The system connection in Australia and New Zealand is as below.

- For safety, the neutral (N) cables of the grid and backup-load sides must be connected together.
- The PE terminal of the BACK-UP port is not connected.
- The E-BAR and the N-BAR must be short-circuited.




4.11. System Application Diagram

CT wire	Corresponding port in the meter
IA (white)	13
IA (blue)	14
IB (white)	16
IB (blue)	17
IC (white)	19
IC (blue)	21



4.12. AFCI

The inverter is equipped with arc-fault circuit interrupter (AFCI). With AFCI protection, when there is an arc signal on the DC side due to aging of the cable or loose contact, inverter can quickly detect and cut off the power to prevent fire, making the PV system run more safely.



5.1. Starting the Inverter


Prerequisite

- The circuit breaker on the AC side is connected properly.
- The DC circuit breaker is connected properly (if applicable).

Procedure

1. Unlock the DC switch and turn it on.
2. Turn on the battery switch (if applicable).
3. Turn on the circuit breaker on the grid side.
4. Configure the initialization settings on the Elekeeper App. For details, refer to Chapter 6 “Commissioning”.
5. Check the LED indicator status on the inverter panel to ensure that the inverter is running properly.












5.1.1. Introduction to the LED Indicators




5.

STARTUP AND SHUTDOWN



LED indicator	Status	Description
	Off	The inverter is powered off.
	Breathing	The inverter is in initialization or standby state.
	Solid on	The inverter is working properly.
	Breathing	The inverter is upgrading
	Solid on	The inverter is not working properly
 System	Solid on	Importing electricity from grid
	On 1s, off 1s	Exporting electricity to grid
	On 1s, off 3s	Not importing and exporting at all
	Off	Off-grid
 Battery	Solid	Battery is discharging
	On 1s, off 1s	Battery is charging
	On 1s, off 3s	SOC low
	Off	Battery is disconnected or inactive
 Grid	Solid on	Connected to grid
	On 1s, off 1s	Counting down to grid connection
	On 1s, off 3s	Grid is not working properly
	Off	No grid
 PV	Solid on	PV array is running properly
	On 1s, off 1s	PV array is not working properly
	Off	PV array is not operating
 Backup	Solid on	AC side load is running properly
	On 1s, off 1s	AC side load overload
	Off	AC side is turned off
 Communication	Solid on	Both BMS and meter communication are good
	On 1s, off 1s	Meter communication is good, BMS communication is lost
	On 1s, off 3s	Meter communication is lost, BMS communication is good

LED indicator	Status	Description
Communication	Off	Both meter and BMS communication are lost
 Cloud	Solid on	Connected
	On 1s, off 1s	Connecting
	Off	Disconnected

5.2. Shutting Down the Inverter

Automatic shutdown

The inverter will be automatically shut down when all the following conditions are met:

- The solar light intensity is insufficient during sunrise and sunset or when the output voltage of the photovoltaic system is lower than the minimum input power threshold of the inverter.
- The battery is neither importing nor exporting the electricity from or to the inverter.
- The grid is neither importing nor exporting the electricity from or to the inverter.

Manual shutdown

To manually shut down the inverter, perform as follows:

1. **PV side:** Turn off the DC switch on the inverter.
2. **Battery side:** Turn off the battery switch.
3. **AC side:** Turn off the circuit breaker on the AC side.

Note: If multiple inverters are connected, turn off their own circuit breakers before turning off the main circuit breaker.

6.

COMMISSIONING




6.1. Installing the App


The Elekeeper (used to be called eSAJ Home) App can be used for both nearby and remote monitoring. It supports Bluetooth/4G or Bluetooth/Wi-Fi to communicate with the device.

On your mobile phone, search for “Elekeeper” in the App store and download the App.

6.2. Logging In to the App and Performing the Initialization Settings



Procedure

1. Open the App and tap on the three-dot icon  on the top right corner.
2. Set the **Language** to **English** and **Network Node** to **Overseas Node**.



3. If you do not have an account, register first.
 - a. Tap **Register**. Choose whether you are an owner or an installer or distributor.
 - b. Follow the instructions on the screen to complete the registration.
4. Use the account and password to log in to the App.
5. Go to the **Tool** interface and select **Remote Configuration**. Tap on **Bluetooth** and enable the Bluetooth function on your mobile phone. Then, tap on **Next**.
6. Choose your inverter according to your inverter SN. Tap on the inverter to enter inverter settings.
7. Complete the inverter settings by following the instructions on the screen.


Example:



6.3. Setting the Protection Parameters

Corresponding modification of protection parameters will take effect only after saving.


Example:



6.4. Reviewing the Inverter Settings

After the above configurations, view the device information.

- Device info: **Basic Info**, **Running Info**, and **Event Info**
- Initialization: **Country** and **Grid Compliance**.




6.5. Configuring the Remote Monitoring

Connect the inverter to the Internet by using the 4G/Wi-Fi/eSolar AI03 module and upload the inverter data onto the server. Users can monitor the inverter operating information remotely from the eSolar Web portal or the Elekeeper App in their mobile phones.

For details, refer to the user manual of the communication module.

6.6. Selecting the Working Mode

Select one of the working modes based on your needs:



Self-consumption Mode: When the solar is sufficient, electricity generated by photovoltaic system will be supplied to load first, the surplus energy will be stored in battery, then the excess electricity will be exported to the grid. When the solar is insufficient, the battery will release electricity to supply load.

Back-up Mode: Reserved Backup SOC setting value can be adjusted, when battery SOC is less than reserved SOC value, battery can only be charged, until SOC reaches reserved value, the battery will be stopped charging; when SOC is larger than SOC setting value, battery will behave as Self-use mode.


Time-of-use Mode: Battery charging period and discharging period can be set, during charging period, battery can only be charged, while in discharging period, battery can only be discharged, the rest of the period, battery will behave as Self-use mode.

6.7. Configuring the Export Limit

On the **Local Connection** page, tap **Export/Generation Limitation Setting** and enter the password “201561”. There are two methods to control the export limit, the two methods are alternative to each other.

Method 1: Export Limitation Settings is to control the electricity exported to the grid.

Method 2: On-Grid Three-Phase Unbalanced Output is to control the electricity generated by the inverter.




6.8. Configuring the Reactive Power Control

6.8.1 Setting the Fixed Power Factor Mode and Fixed Reactive Power Mode


Select **Inductive Adjustment (Var)** or **Capacitive Var** according to your local regulations.

The power ranges from $-60\% P_n$ to $60\% P_n$.

Fixed power factor mode



Fixed reactive power mode



6.8.2 Setting the V-Watt and Volt-Var Modes

This inverter complies with AS/NZS 4777.2: 2020 for power quality response modes. The inverter satisfies different regions of DNSPs' grid connection rules requirements for volt-watt and volt-var Settings. For example, AS4777 series setting is as shown below.




Figure 6. 1

Curve for a Volt-Watt response mode (AS4777 Series)





Figure 6. 1

Curve for a Volt-Var control mode (AS4777 Series)


1. Select corresponding grid compliance according to state regulation during installation.
AS4777 grid compliance has been set during production.
You can choose a state regulation compliance with your local grid on Elekeeper.
2. Log in to Elekeeper.
3. Click **V-Watt/V-Var** to enter the DNSPs settings. Choose a suitable state regulation from the drop-down list.



Notes:

Regarding to the power rate limitation mode, SAJ sets the product WGra to 16.67% Pn by default in the following cases according to the requirements of 3.3.5.2 as 4777.2: 2020.

1. Soft ramp up after connection.
2. Reconnect or soft ramp up/down following a response to frequency disturbance.




For any errors reported as below, contact the after-sales for service support. The operations and maintenance must be performed by authorized technicians.


Error code	Error message	Error code	Error message
1	Master Relay Error	34	Master Bus Voltage Low
2	Master EEPROM Error	35	Master Grid Phase Lost
3	Master Temperature High Error	36	Master PV Voltage High
4	Master Temperature Low Error	37	Master Islanding Error
5	Lost Communication M<->S	38	Master HW Bus Voltage High
6	GFCI Device Error	39	Master HW PV Current High
7	DCI Device Error	40	Master Self-Test Failed
8	Current Sensor Error	41	Master HW Inv Current High
9	Master Phase1 Voltage High	42	Master AC SPD Error
10	Master Phase1 Voltage Low	43	Master DC SPD Error
11	Master Phase2 Voltage High	44	Master Grid NE Voltage Error
12	Master Phase2 Voltage Low	45	Master Fan1 Error
13	Master Phase3 Voltage High	46	Master Fan2 Error
14	Master Phase3 Voltage Low	47	Master Fan3 Error
15	Grid Voltage 10Min High	48	Master Fan4 Error
16	Off Grid Output Voltage Low	49	Lost Communication between Master and Meter
17	Off Grid Output Short Circuit	50	Lost Communication between M<->S
18	Master Grid Frequency High	51	Lost Communication between inverter and Grid Meter
19	Master Grid Frequency Low	52	HMI EEPROM Error
20	BAT Input Mode Error	53	HMI RTC Error
21	Phase1 DCV High	54	BMS Device Error
22	Phase2 DCV High	55	BMS Lost. Conn
23	Phase3 DCV High	56	CT Device Err
24	Master No Grid Error	57	AFCI Lost Err
25	DC Reverse Connect Error	58	Lost Com. H<->S Err
26	Parallel machine CAN Com Error	59	Lost Communication between inverter and PV Meter
27	GFCI Error	61	Slave Phase1 Voltage High
28	Phase1 DCI Error	62	Slave Phase1 Voltage Low
29	Phase2 DCI Error	63	Slave Phase2 Voltage High
30	Phase3 DCI Error	64	Slave Phase2 Voltage Low
31	ISO Error	65	Slave Phase3 Voltage High
32	Bus Voltage Balance Error	66	Slave Phase3 Voltage Low
33	Master Bus Voltage High	67	Slave Frequency High

TROUBLESHOOTING



Error code	Error message
68	Slave Frequency Low
73	Slave No Grid Error
74	Slave PV Input Mode Error
75	Slave HW PV Curr High
76	Slave PV Voltage High
77	Slave HW Bus Volt High
81	Lost Communication D<->C
83	Master Arc Device Error
84	Master PV Mode Error
85	Authority expires
86	DRM0 Error
87	Master Arc Error
88	Master SW PV Current High
89	Battery Voltage High
90	Battery Current High
91	Battery Charge Voltage High
92	Battery Over Load
93	Battery Soft Connect Time Out
94	Output Over Load
95	Battery Open Circuit Error
96	Battery Discharge Voltage Low





APPENDIX



8.1. Recycling and Disposal

This device should not be disposed as a residential waste.

An inverter that has reached the end of its operation life is not required to be returned to your dealer; instead, it must be disposed by an approved collection and recycling facility in your area.

8.2. Transportation

Be careful with the product transportation and storage. Keep less than 5 cartons of inverter in one stack.

8.3. Warranty

Check the product warranty conditions and terms on the SAJ website: <https://www.saj-electric.com/>

8.4. Contacting Support

Guangzhou Sanjing Electric Co., Ltd.

Address: SAJ Innovation Park, No.9, Lizhishan Road, Guangzhou Science City, Guangdong, P.R.China.

Postcode: 510663

Website: <https://www.saj-electric.com/>

Technical Support & Service

Tel: +86 20 6660 8588

Fax: +86 206660 8589

E-mail: service@saj-electric.com

International Sales

Tel: 86-20-66608618/66608619/66608588/66600086

Fax: 020-66608589

E-mail: info@saj-electric.com

China Sales

Tel: 020-66600058/66608588

Fax: 020-66608589

8.5. Trademark

SAJ is the trademark of Sanjing.