




GUANGZHOU SANJING ELECTRIC CO.,LTD



Tel: (86)20 66608588 Fax: (86)20 66608589 Web: www.saj-electric.com

Add: SAJ Innovation Park, No.9, Lizhishan Road, Science City, Guangzhou High-tech Zone, Guangdong, P.R.China

V1.1



eManager-C1 Pro

SMART COMMUNICATION BOX

USER MANUAL

Preface

Thank you for choosing SAJ products. We are pleased to provide you first-class products and exceptional service.

This manual provides information about installation, operation, maintenance, troubleshooting and safety. Please follow the instructions of this manual so that we can ensure delivery of our professional guidance and whole-hearted service.

Customer-orientation is our forever commitment. We hope this document proves to be of great assistance in your journey for a cleaner and greener world.

We make constant improvements on the products and their documentation. This manual is subject to change without notice; these changes will be incorporated in new editions of the publication. To access the latest documentation, visit the SAJ website at <https://www.saj-electric.com/>.


Guangzhou Sanjing Electric Co., Ltd.

TABLE OF CONTENTS

1. SAFETY PRECAUTIONS	1
1.1. Application Scope.....	2
1.2. Safety	2
1.3. Safety Levels.....	2
1.4. Symbol Explanation	3
1.5. Safety Instructions.....	3
1.6. Safe Handling	3
2. Product Information	5
2.1. Application Topology Diagram.....	6
2.2. Main Features	6
2.3. Dimension.....	7
2.4. Port Introduction	8
2.5. Datasheet.....	8
2.6. Internal Structure.....	10
2.7. EMS Control Module (eManager-C1-1)	11
2.7.1. Front view.....	11
2.7.2. Rear view	13
2.8. EMS Power Module (eManager-C1-2)	16
2.8.1. Front view.....	16
2.8.2. Rear view	17
2.9. DC-DC Module	17
2.10. Smart Meter.....	18
2.11. Switch	18
3. Installation	19
3.1. Unpacking and Inspection	20
3.2. Installation Environment Requirements	20
3.3. Installation Location Requirements.....	21
3.4. Installation Procedure.....	22
4. Electrical Connection	23
4.1. Unlocking the Box.....	24
4.2. Assembling the Communication Connection	24
4.2.1. To the Smart Meter	24
4.2.2. To the EMS Control Module	25
4.3. Connecting the Ethernet Ports on the Switch	25
4.4. Connecting Other Required Ports (Optional).....	26
4.4.1. DRED Connection (Australia)	26
4.4.2. RCR Connection (Germany).....	27
4.5. Connecting the Power Supply	27
4.5.1. Connecting the 230 V AC Power Supply.....	27
4.5.2. Connecting the 12 V DC Power Supply	28
4.6. Grounding	29
4.7. Connecting the Smart Meter	30
4.8. Turning on the Circuit Breaker.....	31
4.9. Locking the Box.....	31
5. Commissioning by App	33
5.1. Downloading the Elekeeper App	34
5.2. Logging In to the App.....	34
5.3. Completing the Initialization Settings	35
5.4. Configuring Other Devices Connected to the eManager	43
5.5. Creating a plant.....	43
6. Configurations by Web	47
6.1. Logging In to the Web Platform.....	48
6.2. Creating a Plant.....	49
6.3. View the Plant Statistics.....	52
7. Operations by LAN (Near End)	55
7.1. Connecting the EMS to the Computer.....	56
7.2. Logging In to the Local Web.....	56
7.3. Viewing the Device Information.....	58

8. Appendix..... 61

- 8.1. Recycling and Disposal 62
- 8.2. Transportation 62
- 8.3. Warranty..... 62
- 8.4. Contacting Support 62
- 8.5. Trademark..... 62



1.

SAFETY PRECAUTIONS



1.1. Application Scope

This user manual provides instructions and detailed procedures for installing, operating, and maintaining the SAJ product:

eManager-C1 Pro

1.2. Safety

CAUTION:

ONLY qualified and trained electricians who have read and fully understood all safety regulations contained in this manual can install, maintain, and repair the equipment. Access to the equipment is by the use of a tool, lock and key, or other means of security.

1.3. Safety Levels

 DANGER
Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

 WARNING
Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 CAUTION
Indicates a hazardous condition which, if not avoided, could result in minor or moderate injury.

 NOTICE
Indicates a situation which, if not avoided, can result in property damage.

1.4. Symbol Explanation

Symbol	Description
	Dangerous electrical voltage This device is directly connected to public grid, thus all work to the device shall only be carried out by qualified personnel.
	No open flames Do not place or install near flammable or explosive materials.
	Attention Install the product out of reach of children.
	This device shall NOT be disposed of in residential waste.
	CE Mark Equipment with the CE mark fulfills the basic requirements of the Guideline Governing Low-Voltage and Electro-magnetic Compatibility.
	Recyclable
	Avoid liquid or moisture

1.5. Safety Instructions

Keep the manual for future reference.

To prevent personal injury and property damage and to ensure long-term operation of the product, be sure to read all the safety instructions in this section carefully prior to any works and observe the appropriate rules and regulations of the country or region where you install the device.

1.6. Safe Handling

The product has been designed and tested strictly according to international safety regulations. As an electrical and electronic equipment, it must be installed, commissioned, operated, and maintained in strict accordance with related safety instructions. Incorrect operation or misuse of this device may cause personal injury or device damage. This will void the limit warranty and SAJ will not be responsible for the loss caused by those behaviors.

- The eManager-C1 Pro must be installed and maintained by authorized technicians based on local laws and regulations.
- Before installing or maintaining the eManager-C1 Pro, make sure that it is disconnected from the grid.
- When the eManager-C1 Pro is working, do not touch the internal component or cable to avoid electric shock.
- Before replacing an internal component within the eManager-C1 Pro, make sure that the eManager-C1 Pro is disconnected from the grid and the new component meets the usage requirement.
- When the eManager-C1 Pro is working, do not plug in or out the cables.
- During installation, make sure that the lightning protection module within the eManager-C1 Pro is grounded properly.
- Make sure the AC input voltage and current are compatible with the rated voltage and current of the eManager-C1 Pro; otherwise, components might be damaged, or the device cannot work properly.

2.

PRODUCT INFORMATION



2.1. Application Topology Diagram




Figure 3.1 Application typology diagram

2.2. Main Features

SAJ eManager-C1 Pro smart communication box (hereinafter called the eManager) is applied to the photovoltaic (PV) energy storage system (ESS). It is a comprehensive solution that integrates the following components:

- Energy management system (EMS) controller
 - EMS control module (eManager-C1-1)
 - EMS power module (eManager-C1-2)
- Ethernet switch
- Smart meter
- Air circuit breaker
- DC-DC power module

The eManager-C1 Pro provides the following functions:

- All-in-one compact design
- Smart and flexible support
 - Support for RS485, Ethernet, 4G, and Bluetooth communication
 - Support for data collection/transmission/storage for energy meters, conditioners, fire protection devices, sensors, and other equipment
 - Support for communication and monitoring on a maximum of 10 inverters
- Convenient operation and maintenance
 - Batch parameter settings and firmware updates for inverters
 - 24-hour local and remote monitoring
 - Remote operation: PV-plant maintenance on Web
- Easy operation
 - All-in-one compact design for easy installation
 - IP65 protection box enclosure for easy maintenance

2.3. Dimension




Figure 3. 2
Dimension

2.4. Port Introduction




Figure 3. 3
Ports

Silkscreen	Description
LAN	Ethernet port (waterproof)
POWER AC_IN	AC power cable port (waterproof)
COM 0	Reserved Ethernet/antenna port (waterproof)
COM 1	DC power cable port
COM 2	Reserved

Table 3. 1
Ports

2.5. Datasheet

General parameters	
Application	Commercial project monitoring
Communication	Bluetooth, 4G, Ethernet, or RS485
Data collection interval (Min)	1 – 30 (optional); 5 (standard)
Firmware update	Ethernet, USB, or remote update
Data access	App, Web, or local Web
Electrical parameters	
Input AC voltage	176 – 300 V AC
Input DC voltage	9 – 36 V

Input frequency	50/60 Hz
Max. power	50 W
Operating temperature range	-25°C to +60°C (-13°F to +140°F)
Ambient humidity	5% – 95% (non-condensing)
Dimension (H x W x D) (mm)	300 x 400 x 170
Weight (kg)	7.5
Protective class	I
Ingress protection	IP65
Mounting	Wall-mounted

Table 3. 2
Datasheet

2.6. Internal Structure




Figure 5. 1
Internal structure

Callout	Description
1	EMS control module (eManager-C1-1)
2	EMS power module (eManager-C1-2)
3	Smart meter
4	Switch
5	Circuit breaker
6	DC-DC power module

Table 5. 1
eManager-C1-1

2.7. EMS Control Module (eManager-C1-1)

2.7.1. Front view




Figure 5. 2
eManager-C1-1 front view

Silkscreen	Description	Remarks
ANT	Antenna	SMA port
COM	Debugging serial port	DB9 port
LVDS	Low Voltage Differential Signaling (LVDS) display port	DVI port
NET1	Fast Ethernet (FE) port	RJ45 port
NET2	FE port	RJ45 port
ADC	Isolated ADC port	3.5-08P terminal
RS485	Isolated RJ45 port	3.81-12P terminal
CAN-bus	Isolated CAN-bus port	3.81-12P terminal

Table 5. 2
Front-port description

ANT

When a 4G module is inserted into the mini-PCIe slot, a 4G antenna needs to be connected to this port.

LVDS (Reserved for future use)

The LVDS display port is a DVI port.

NET1 and NET2

The two FE ports use RJ45 physical ports and 10 Mbps/100 Mbps self-adaption. Each port has two LED indicators on the left and right sides, as listed in the following table.

LED	Location	Color	Function	Description
1	Left	Yellow	LINK	Solid on when the network is connected.
2	Right	Green	Active	Blinks when the network connection is active.

RS485

Four isolated RS485 ports are provided by a 3.81-12P terminal.

Silkscreen	Description	Silkscreen	Description	Silkscreen	Description
485A1	First RS485 A signal	485B1	First RS485 B signal	485G1	First RS485 signal ground
485A2	Second RS485 A signal	485B2	Second RS485 B signal	485G2	Second RS485 signal ground
485A3	Third RS485 A signal	485B3	Third RS485 B signal	485G3	Third RS485 signal ground
485A4	Fourth RS485 A signal	485B4	Fourth RS485 B signal	485G4	Fourth RS485 signal ground

CAN-bus

Three isolated CAN ports are provided by a 3.81-12P terminal.

ADC

Four isolated ADC ports are provided by a 3.5-08P terminal. Four ADC share the AGND.

2.7.2. Rear view




Figure 5.3
eManager-C1-1 rear view

Silkscreen	Description
POWER	Power connection. Provided by a 3.81-03P terminal.
DO	Dry output (DO) ports provided by three 3.5-08P terminals. <ul style="list-style-type: none"> • VCC, GND, high side driver (HSD), and low side driver (LSD) ports • DO1 – DO8 isolated ports <ul style="list-style-type: none"> - DO1 – DO4: Mechanical relay (passive) - DO5 – DO8: Solid-state relay (passive)
PWR	Power status indicator
RUN	System running status indicator
ERR	System error indicator
STA	Wireless module status indicator
LED1, LED2, LED3, LED4	Reversed for future use
RESET	Reset button. Press it to reset the system.
USB	Two USB 2.0 ports
TF-Card	TF card slot
Nano-SIM	Nano-SIM card slot. You can buy a nano-SIM card for use.
DI1 – DI8u	Isolated dry input (DI) ports provided by two 3.5-08P terminals <ul style="list-style-type: none"> • HDI: High-level voltage input (VIH) (passive) • LDI: Low-level Voltage input (VIL) (active)

Table 5.3
Rear-port description


POWER

24 V DC and 500 mA. This port has three pins with 3.81 mm spacing in between. It provides two screw holes.

Silkscreen	Description
12-24V	System power input
EARTH	Protecting earthing
GND	System power ground

HSD and LSD

The eManager-C1-1 provides four high side driver (HSD) ports and two low side driver (LSD) ports.



Silkscreen	Description	Silkscreen	Description
VCC	Voltage collector-to-collector. Same as the system power supply voltage.	LSD1-	Low side driver
LSD2-	Low side driver	GND	Ground
HSD1+	High side driver	HSD2+	High side driver
HSD3+	High side driver	HSD4+	High side driver

LED

The eManager-C1-1 provides eight LED indicators.

Silkscreen	Description	Silkscreen	Description
PWR	Power status indicator. <ul style="list-style-type: none"> • Red: The system is powered on. • Off: The system is powered off. 	RUN	System running status indicator. <ul style="list-style-type: none"> • Blinking in green: The system is running normally. • Off: The system does not work.
ERR	System error indicator.	STA	Wireless module status indicator.

Silkscreen	Description	Silkscreen	Description
	<ul style="list-style-type: none"> ● Red: An error occurs. ● Off: The system is running normally. 		<ul style="list-style-type: none"> ● Green: The module is running normally. ● Off: The module is running abnormally.
LED1	Programmable. Green.	LED2	Programmable. Green.
LED3	Programmable. Green.	LED4	Programmable. Green.

RESET

Silkscreen	Description
RESET	You can insert a proper tool, such as a paper clip, to the hole to reset the system.

USB

The USB hub chip provides two USB 2.0 ports for connecting to a USB flash drive, a mouse, or a keyboard.

Silkscreen	Description
USB	The two USB 2.0 ports are provided by a USB hub chip developed based on the host controller USB1.

TF-Card

The eManager-C1-1 provides a standard TF card slot. A TF card is used for system debugging, firmware read and write, startup and update.

Nano-SIM



Nano-SIM

The eManager-C1-1 provides an internal mini-PCIe interface and an external Nano-SIM card slot for inserting a standard SIM card with 4G function.

DO1 – DO8 (Reserved for user use)

The eight relay isolated passive DO ports can be used to control the power on and off for the external devices.

DI1 – DI8 (Reserved for user use)

Eight optically-coupled isolation DI ports, including four VIH (active) ports and four VIL (active) ports.

2.8. EMS Power Module (eManager-C1-2)

2.8.1. Front view




Figure 5. 4
eManager-C1-2 front view

Silkscreen	Description
POWER AC_IN	Power supply port
DRED/RCR	DRED/RCR function terminal
DC/OUT (+24 GND)	DC output terminals. The two will be connected to the POWER port of the EMS control module and the POWER port of the switch.

Table 5. 4
Front-port description

DRED/RCR

This port is compatible with the ripple control receiver (RCR) and demand response enabling device (DRED) functions. (DRED is used in Australia; RCR is widely used in Germany.)

Note: If you do not need this function, no connection is required for this port.

Silkscreen	1	2	3	4	REF1	REF2
DRED	DRM1/5	DRM2/6	DRM3/7	DRM4/8	RefGen	Com/DRM0
RCR	D_IN1	D_IN2	D_IN3	D_IN4	+5V	+5V

Table 5. 5
Rear-port description

2.8.2. Rear view





Figure 5.5
eManager-C1-2 rear view

Silkscreen	Description
RS232	RS232 terminal
ANT	Antenna terminal
PWR	Power status indicator
RUN	System running status indicator

Silkscreen	Description
Ctrl	For enabling or disabling the module.
GND	For connecting the negative DC power cable.
Vin	For connecting the positive DC power cable.

2.9. DC-DC Module



2.10. Smart Meter

For detailed information, refer to the meter product document.

2.11. Switch

For detailed information, refer to the switch product document.

3.

INSTALLATION



3.1. Unpacking and Inspection

If there are missing or damaged components, contact after sales.





			
eManager-C1 Pro*1	Expansion bolt*4	Grounding OT terminal*1	Lock with a key*1
			
Cable terminal*4	Six-pin connector*1	Hexagon flange nut*1	Mounting lug*4
			
ST4.8 screw*8	Document*1		

Table 4. 1
Package content

3.2. Installation Environment Requirements

- Install the eManager-C1 Pro in a place without vibration or shock and avoid exposure to direct sunlight, rain, and snow erosion.
- Keep the eManager-C1 Pro away from explosive chemicals, any gas which might corrode the metal, or any conducting dust which might destroy the insulation.
- For easy installation and maintenance, it is recommended to install the eManager-C1 Pro at eye level.
- Secure the eManager-C1 Pro on a firm surface to bear its weight.




Figure 4. 1
Installation environment

3.3. Installation Location Requirements

- Reserve enough clearance around the box to ensure a good air circulation at the installation area.




Figure 4. 2
Space

- Install the eManager vertically or backwards with the maximum angle of 15 degrees. Do not tilt it leftwards or rightwards.




Figure 4. 3
Installation position

3.4. Installation Procedure

- Use the ST4.8 screws to secure the four mounting plugs on the four corners of the eManager.




Figure 4. 4
Installing the eManager

- Lift the eManager onto the wall to mark positions for drilling holes and put it down.
- Drill four holes with 8-mm diameter and 45-mm depth in the wall.
- Lift the eManager upwards and align the mounting plugs to the drilled holes. Use four expansion bolts and four screws to secure the eManager to the wall.





Figure 4. 5
Installing the eManager

---End

4.

ELECTRICAL
CONNECTION

4.1. Unlocking the Box

Hold the two tabs and lift it upwards. Then, lift the cover up.




Figure 6. 1
Unlocking the box

4.2. Assembling the Communication Connection

4.2.1. To the Smart Meter

About this task

To locate the smart meter, refer to Section 2.6 “Internal Structure”.

Procedure

1. Prepare the communication cables.
2. Loosen the nut from the cable gland “COM0” at the bottom of the eManager.
3. Connect the cables to terminals 19 and 21 on the smart meter.
4. Tighten the nut back to the cable gland “COM0”.

---End

4.2.2. To the EMS Control Module

About this task

To locate the eManager-C1-1 module and its RS485 ports, refer to Section 2.6 “Internal Structure” and Section 2.7.1 “Front view”.

Procedure

1. Prepare the communication cables.
2. Loosen the nut from the cable gland “COM1” or “COM2” at the bottom of the eManager.
3. Insert the cables through the nut and then the cable gland.
4. Insert the cables to the RS485 ports on the eManager-C1-1 module, as listed below.

485A2	485B2
485A3	485B3
485A4	485B4

Note: 485A1 and 485B1 are pre-connected to terminals 24 and 25 on the smart meter.

5. Tighten the nut back to the cable gland “COM1” or “COM2”.

---End

4.3. Connecting the Ethernet Ports on the Switch

About this task

To locate the switch, refer to Section 2.6 “Internal Structure”.

The switch provides 16 Ethernet ports with one pre-connected to the NET1 port on the EMS control module and the other 15 reserved for connecting multiple inverters.

Procedure

1. Prepare the Ethernet cables.
2. Loosen the nut from the cable gland “LAN1” or “LAN2” at the bottom of the eManager. Insert the cable through the nut.

3. Remove the seals from the cable gland. Use a knife to cut through a hole in the seals.
4. Insert the cable through the seals hole and then the cable gland.
5. Insert the cables to the Ethernet ports on the switch.
6. Tighten the nut back to the cable gland “LAN1” or “LAN2”.

---End

4.4. Connecting Other Required Ports (Optional)

Based on your actual needs, you can use the reserved ports, such as the NET2, DO, and DI ports on the eManager-C1-1 module and the DRED/RCR port on the eManager-C1-2 module.

The following lists the detailed information about the DRED/RCR connection. A six-pin connector is provided in the accessory bag.

4.4.1. DRED Connection (Australia)

The DRED signal controlling ports are provided to meet the Australia DERD certification requirements and other regions.




Figure 6. 2
DRED connection

4.4.2. RCR Connection (Germany)

The RCR signal controlling ports are provided to meet the power dispatching requirements in Germany and other countries and regions.




Figure 6.3
RCR connection

4.5. Connecting the Power Supply

4.5.1. Connecting the 230 V AC Power Supply

About this task

To locate the circuit breaker, refer to Section 2.6 “Internal Structure”.

230 V AC power supply is connected to the circuit breaker within the eManager.

Prerequisite

The circuit breaker is in OFF position.


Procedure

1. Prepare the AC power cables by using the provided cable terminals.

Strip the insulation around 10 mm. Assemble the cable terminals by using the crimping pliers.

2. Locate the cable gland POWER AC_IN at the bottom of the eManager and loosen its nut.
3. Insert the power cables through the nut and then the cable gland. Insert the cables to the ports on the circuit

breaker.



4. Tighten the nut back to the cable gland POWER AC_IN.

---End

4.5.2. Connecting the 12 V DC Power Supply

About this task


To locate the DC-DC power module, refer to Section 2.6 “Internal Structure”.

12 V DC power supply is connected to the DC-DC power module within the eManager.

Procedure


1. Prepare the DC power cables by using the provided cable terminals.

Strip the insulation around 10 mm. Assemble the cable terminals by using the crimping pliers.



2. Locate the cable gland COM1 at the bottom of the eManager and loosen its nut.

3. Insert the power cables through the nut and then the cable gland.
4. Insert the negative cable to the GND port and the positive cable to the Vin port on the 12 V DC module.



5. Tighten the nut back to the cable gland COM1.

---End

4.6. Grounding

Procedure

1. Insert the grounding cable through the cable gland POWER AC_IN at the bottom of the eManager.
2. Prepare an OT terminal.




Figure 6.4
Preparing an OT terminal

Callout	Description	Callout	Description	Callout	Description
a	Cable	b	Heat shrink tubing	c	OT terminal
d	Hydraulic pliers	e	Heat gun		

3. Locate the grounding bolt. Install the OT terminal to the bolt and tighten it by using the hexagon flange nut.




Figure 6.5
Installing the OT terminal

Callout	Description
a	OT grounding terminal
b	Hexagon flange nut

---End

4.7. Connecting the Smart Meter

About this task

To locate the smart meter, refer to Section 2.6 “Internal Structure”.


Procedure

1. Connect the grid cables to the UA, UAB, UC, and UN terminals on the smart meter.
2. Connect the cables of three current transformers (CT) to terminals 31, 33, 34, 36, 37 and 39 on the smart meter.

From (CT)	To (meter)
IA*	31
IA	33

From (CT)	To (meter)
IB*	34
IB	36

From (CT)	To (meter)
IC*	37
IC	39



4.8. Turning on the Circuit Breaker

Turn on the circuit breaker by toggling down the switch.

4.9. Locking the Box

Close the box cover. Press the tabs to lock the cover.




Figure 6. 6
Locking the box

5.

COMMISSIONING BY APP



The Elekeeper App can be used for both nearby and remote monitoring. It supports Bluetooth/4G or Bluetooth/Wi-Fi to communicate with the device.


5.1. Downloading the Elekeeper App

On your mobile phone, search for “Elekeeper” in the App store and download the App.

5.2. Logging In to the App

Procedure


1. Open the App and click the three-dot icon  on the top right corner.
2. Set the **Language** to **English** and **Network Node** to **Overseas Node**.



3. If you do not have an account, register first.
 - a. Click **Register**. Choose whether you are an owner, installer, or distributor.
 - b. Follow the instructions on the screen to complete the registration.
4. Use the account and password to log in to the App.
5. Go to the **Service** interface and select **Remote Configuration**.
6. Verify that Bluetooth is enabled on your mobile phone. Click **Bluetooth** and then **Next**.


5.3. Completing the Initialization Settings

1. Choose your EMS from the device list. Then, click **Initialization**.




2. Set the network connection. Then, click **Save**.

Example:




3. After the message “Network normal” is displayed, click **Next**.




4. Add the required devices to connect to the eManager. Then, click **Next**.

Example:



- Set the meter connection type. Then, click **Next**.


Example:



- Set the strategy. Then, click **Next**.



To set a new strategy, click **template** on the top right corner.

Example:



7. Select your country and set the device time. Then, click **Next**.

Example:



8. View the eManager information that you have just set to make sure that all settings are proper.
 - To restart the device, choose **More configuration > Restart device**.
 - To restore the device to factory settings, choose **More configuration > Restore Factory Settings**.


5.4. Configuring Other Devices Connected to the eManager

To configure other devices that are connected to the eManager, refer to the commissioning content in their own user manuals.

5.5. Creating a plant


You can also create a plan through the SAJ Web portal. For details, refer to Chapter 6 “**CONFIGURATIONS BY WEB**”.

1. On the **Management** tab, click the \oplus icon on the top right corner. Select **Create Plant for Me**.






2. Scan the SN barcode on the power label or input the SN manually. Click \oplus to add the device. Then, click **Next Step**.

Example:



3. Configure the plant settings. Then, click **Create Plant**.



6.

CONFIGURATIONS BY WEB

The eSAJ All-In-One Smart EMS Web platform is a smart family energy management system which can monitor the power production and consumption statistics.

Most of the configuration functions can be completed in the Elekeeper App; however, some data, such as the smart meter, air conditioning, fire protection, and power curve, can only be viewed on the Web platform.

6.1. Logging In to the Web Platform


1. Go to <https://esaj-home.saj-electric.com>.
2. For the first-time login, register first.
 - a. Click **Don't have an account yet? Register now.**
 - b. Follow the instructions to complete registration.

- c. Use the account and password to log in to the platform.



6.2. Creating a Plant


1. On the **Home** page, choose **Monitoring > Plants** on the left navigation pane. Then, click Add plant on the upper right corner.





2. In the displayed Create Plant window, follow the instructions on the screen.
 - a. On the **Add a device** pane, enter the device SN and click **Add**.



For the inverter, input the device capacity.



- b. On the **Plant Info** pane, enter the plant name and longitude and set **Province/Autonomous region/Municipality** according to your needs. Then, configure the plant details, such as the address, type, and capacity.



- c. On the **Alarm push** pane, enable the **Alarm push** function. Configure the **Alarm level**, **Push channel**, and **Push users** (up to 5 users). Then, click **Next Step**.

Create Plant

Add a device

Plant Info

Alarm push

Alarm level

General Important Urgent

Push channel

app Email

Push users (Up to 5 users)

No data

Next Step

- d. On the Report pane, set the email address for receiving the plant reports and alarms. Then, click **Creation is complete** to finish the plant creation process.

Create Plant

Add a device

Plant Info

Alarm push

Report

Plant report/Alarm receiving email address setting

Add an email address Add up to five email addresses

Creation is complete


6.3. View the Plant Statistics

- On the **Home** page, choose **Monitoring > Plants** on the left navigation pane. Search for your plant name and click **Search**. Then, click the required plant.

Status	Plant Name	Plant Type	Power	Production Today	Lifetime Production	Installed capacity	Creation time	Owner	Operation
Online	EMS	Energy Storage	11704 W	21.3 kWh	1518.5 kWh	50 kWp	2023-11-11 15:22:24		
Offline		Energy Storage	0 W	0 kWh	0 kWh	50 kWp	2023-10-09 16:38:55		
Offline		Energy Storage	0 W	0 kWh	0 kWh	3 kWp	2023-08-31 11:37:34		
Offline		Energy Storage	0 W	0 kWh	0 kWh	50 kWp	2023-08-29 08:48:07		
Offline		Energy Storage	0 W	0 kWh	344.8 kWh	100 kWp	2023-08-28 20:27:08		
Offline		Energy Storage	0 W	0 kWh	0 kWh	12 kWp	2023-08-23 15:16:26		

- View the plant statistics.

- On the **Overview** page, you can view today's production, consumption, importation, exportation, charging, and discharging data. Meanwhile, you can scroll down to check more in following areas:
 - Energy overview:** It provides a dynamic connection diagram between PV arrays, grid, inverter, loads, and batteries.
 - Plant Info:** It lists plant address, owner name, capacity, and creation time.
 - Energy analysis:** You can view the electric energy production and consumption by day, week, month, year, or in total. In addition, you can click **Export** on the right corner of this area to view the data in Excel format.
 - Energy comparison:** You can select different types of energy from the drop-down list to view the energy by month, quarter, or year.
 - Plant weather:** It shows the current whether in your local area.
 - Social contribution:** It provides the CO2 emission reduction and standard coal saving statistics and converts the saving to contributions of planted trees.



- On the **Device** page, you can view statistics of the **EMS, Inverter, Battery, Air conditioning, and Fire Protection.**

- **Open:** Current alarm
- **Closed:** History alarms

Status	Alarm name	Inverter SN	Alarm plant	Alarm occurrence time	Alarm recovery time	Operation
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-09 18:55:27	2023-11-09 19:53:56	△
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-09 17:12:40	2023-11-09 17:20:16	△
●	Low Battery Discharge Voltage Fault	[REDACTED]	EMS	2023-11-09 17:12:21	2023-11-09 17:12:40	△
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-09 17:04:19	2023-11-09 17:11:09	△
●	Low Battery Discharge Voltage Fault	[REDACTED]	EMS	2023-11-09 17:03:59	2023-11-09 17:04:19	△
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-09 16:41:27	2023-11-09 16:56:40	△
●	Low Battery Discharge Voltage Fault	[REDACTED]	EMS	2023-11-09 16:40:59	2023-11-09 16:41:27	△
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-08 18:26:37	2023-11-08 18:48:10	△
●	Low Battery Discharge Voltage Fault	[REDACTED]	EMS	2023-11-08 18:25:53	2023-11-08 18:26:37	△
●	Battery Open Circuit Fault	[REDACTED]	EMS	2023-11-08 16:57:21	2023-11-08 16:57:47	△

Status	SN	Type	Device model	Power	Production Today	Lifetime Production	Operation
●	GH[REDACTED]	Storage inverter	CH2-50K-T6	11794 W	21.3 kWh	1518.5 kWh	⚙️

- On the **Alarm** page, you can view the alarm details by severity or status.
 - By severity: **Emergency alarm > Important Alarm > General alarm**
 - By status:

7.

OPERATIONS BY LAN (NEAR END)



On this local Web, the real-time device data will be updated once two seconds.

7.1. Connecting the EMS to the Computer


Procedure

1. Prepare an RJ45 cable.
2. Open the EMS box.
3. Connect one end of the cable to either of the following ports in the EMS:
 - Ethernet port on the switch. To locate the switch, refer to Section 2.6 “Internal Structure”.
 - NET2 port on the eManager-C1-1 module. To locate the NET2 port, see Section 2.7.1 “Front view”.
4. Connect the other end of the cable to your computer.

---End

7.2. Logging In to the Local Web

1. Open your computer, set the IP address, subnet mask, and default gateway.
 - a. In **Settings**, select **Network & internet** on the left navigation pane and then select **Advanced network settings** on the right pane.




- b. Select the Ethernet network. Locate **More adapter options** and click **Edit**.
- c. In the displayed dialog box, select the Internet protocol version and click **properties**.
- d. In the displayed dialog box, select Use the following IP address and set as follows:

Use the following IP address:

IP address:	192 . 168 . 1 . 110
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	192 . 168 . 1 . 1

2. Open the browser and enter the following IP address in the address bar.
Depending on the EMS port used for connection, the IP addresses varies:
 - Ethernet port on the switch: 192.168.1.136
 - NET2 on the EMS control module: 192.168.2.136
3. Use the account **sajComm** and password **080808** to log in.




4. (Recommended) To change the password, click the account name **sajComm** on the upper right corner and select **Personal center**. Then, follow the instructions on the screen to set a new password.




7.3. Viewing the Device Information

1. To view the device information, click the **Device** tab and select the required device from the list on the left-side.





2. To check the reported alarms, click the **Device** tab to view them in different status.

- **Open:** Current alarm
- **Closed:** History alarms



3. To view and configure the strategy, click the **Strategy** tab.

- **Local strategy:** View the current strategy.
- **Configure strategy:** Modify the strategy.
- **Strategy template:** Create a new strategy.



8.1. Recycling and Disposal

This device should not be disposed as a residential waste.

The device that has reached the end of its operation life is not required to be returned to your dealer; instead, it must be disposed by an approved collection and recycling facility in your area.

8.2. Transportation

Be careful with the product transportation and storage.

8.3. Warranty

Check the product warranty conditions and terms on the SAJ website: <https://www.saj-electric.com/>

8.4. Contacting Support

Guangzhou Sanjing Electric Co., Ltd.

Address: SAJ Innovation Park, No.9, Lizhishan Road, Guangzhou Science City, Guangdong, P.R.China.

Postcode: 510663

Website: <https://www.saj-electric.com/>

Technical Support & Service

Tel: +86 20 6660 8588

Fax: +86 206660 8589

E-mail: service@saj-electric.com

International Sales

Tel: 86-20-66608618/66608619/66608588/66600086

Fax: 020-66608589

E-mail: info@saj-electric.com


China Sales

Tel: 020-66600058/66608588

Fax: 020-66608589

8.5. Trademark

SAJ is the trademark of Sanjing.



APPENDIX

